

Fulbrook Lane, Sherbourne, Warwick, CV35 8AR, ENGLAND

> Tel: 01926 624800 Fax: 01926 624900

#### MICRO SYSTEM RADIO INTERFACE UNITS

# RADIO TYPE CONFIGURATION

REF: E002-8 11-06-08

## CONFIGURATION INSTRUCTIONS

Lynx Radio Interface Units can be configured to operate with several types of radio.

To re-configure an Interface, first remove the back of the unit by unfastening the four retaining screws. Situated on the circuit board inside the unit, is an eight-way switch which should be set in accordance with the following diagrams.

After configuration always re-label the interface unit to indicate its present setting.


### WARNING:

Incorrect configuration may damage the unit and any radio which is connected.

Opening the back of a Lynx Radio Interface invalidates the quarantee.

Icom A2/A20/A21










TYPE A


Alinco







Icom A3/A4/A6/A14/A22/A24





## TYPE C

KING KX99 Sporty A300 Win 747

**IMPORTANT** 

READ THIS INFORMATION CAREFULLY BEFORE ATTEMPTING TO CONFIGURE THIS EQUIPMENT